






LEX/V1 Spare parts list



ITEM	DESCRIPTION	QUANTITY
VEM1-01	Silicon Reduction	1
VEM1-02	Static Equipment, Body	1
VEM1-03	Trough	1
VEM1-04	Screw for Air Gap Setting	1
VEM1-05	Gap Setting Fix Pin	1
VEM1-06	Seating Coil Cover	1
VEM1-07	Coil	1
VEM1-08	Silicon Ring	3
VEM1-09	Leaf Assembly	6
VEM1-10	Leaf Space Plate	16
VEM1-11	Leaf Fixing Plate	4
VEM2-14	Antivibrating Leg	3

ITEM	DESCRIPTION	QUANTITY
VEM1-16	Anti Electric Cable	1
VEM1-18	M5 Nut	4
VEM1-19	M20 Nut	1
VEM1-21	M6 x 16 Bolt	1
VEM1-22	Pg 7 Cable Gland	1
VEM1-23	M6 Spring Washer	1
VEM1-24	M5x8 Bolt	2
VEM1-25	M5 Spring Washer	17
VEM1-31	M5x16 Bolt	4
VEM1-32	M5x20 Bolt	8
VEM1-39	Coil Space Ring	1