






LEX/V2 Spare parts list



ITEM	DESCRIPTION	QUANTITY
VEM1-01	Silicon Reduction	1
VEM2-02	Static Equipment, Body	1
VEM2-03	Trough	1
VEM2-04	Screw for Air Gap Setting	1
VEM2-05	Gap Setting Fix Pin	1
VEM2-06	Seating Coil Cover	1
VEM2-07	Coil	1
VEM2-08	Silicon Ring	3
VEM2-09	Leaf Assembly	7
VEM2-10	Leaf Space Plate	16
VEM2-11	Leaf Fixing Plate	4
VEM2-14	Antivibrating Leg	4

ITEM	DESCRIPTION	QUANTITY
VEM1-16	Anti Electric Cable	1
VEM2-18	M8 Nut	4
VEM1-19	M20 Nut	1
VEM2-21	M8 x 25 Bolt	1
VEM1-22	Pg 7 Cable Gland	1
VEM1-24	M5x8 Bolt	2
VEM1-25	M5 Spring Washer	5
VEM2-27	M8 Spring Washer	4
VEM1-31	M5x16 Bolt	4
VEM2-32	M8x35 Bolt	4
VEM1-33	M8x30 Bolt	4
VEM1-36	Silicon Outer Ring	1
VEM2-39	Coil Space Ring	1