





LEX/V4 Spare parts list



ITEM	DESCRIPTION	QUANTITY
VEM1-01	Silicon Reduction	2
VEM4-02	Static Equipment, Body	1
VEM4-03	Trough	1
VEM3-04	Screw for Air Gap Setting	2
VEM3-05	Gap Setting Fix Pin	2
VEM4-06	Seating Coil Cover	1
VEM4-07	Coil	1
VEM4-08	Armature	1
VEM1-08	Silicon Ring	2
VEM4-09	Leaf Assembly	12
VEM4-10	Leaf Space Plate	20
VEM4-11	Leaf Fixing Plate	4

ITEM	DESCRIPTION	QUANTITY
VEM2-14	Antivibrating Leg	4
VEM1-16	Anti Electric Cable	1
VEM3-18	M10 Nut	4
VEM2-18	M8 Nut	2
VEM1-19	M20 Nut	2
VEM1-22	Pg 7 Cable Gland	1
VEM2-27	M8 Spring Washer	4
VEM3-27	M10 Spring Washer	10
VEM1-31	M5x16 Bolt	2
VEM3-31	M8x20 Bolt	4
VEM3-32	M10x50 Bolt	2
VEM3-33	M10x40 Bolt	4